

HDMI Output Frame Rate Change and OSD Setting

Series 2

Adapt Models: Rugby, Mini Z10TIR, Mini Z10TIR-35, Q10TIR-35, Z10TIRM, WK10TIRM

Software: PL Cloud Platform Control V1.7

1. Connect computer and gimbal serial port by a USB to TTL cable

1) Connection method:


USB to TTL cable GND ----- Gimbal GND (as shown in below image)

USB to TTL cable TX ----- TX (printed on Viewpro gimbal controller Z-3D)

USB to TTL cable RX ----- RX (printed on Viewpro gimbal controller Z-3D)

Diagram:

TTL 3.3v UART baud : 115200/9600(some version) , 8/1/N, HEX




2) The USB to TTL cable connecting photo (Red 5V, Black GND, White RXD, Green TXD)



Install Software “PL Cloud Platform Control V1.7”, start it.


2. Test connection:

- 1) Power on the gimbal camera. Select the current port COM(X);
- 2) Click the “Enlarge”, then camera lens zoom, picture zoom, connecting well.



3. Change the HDMI output frame rate to 1080p30 as following steps :

- 1) Select the correct COM port, the baud rate is 115200, without test;
- 2) Select **1080i/59.9**
- 3) Select the required OSD options, can be selected same as the following pictures if no specific requirements.
- 4) Select **SONY7520**
- 5) Click **OSD settings**




4. According to step 4, select different option in 4.2) to have different HDMI output frame rate.

Different frame rate options in 4. 2) and according HDMI output frame rates please refer to below table:


4.2)	HDMI output
1080i/59.94	1080p/30
1080i/60	1080p/25
1080p/30	1080p/60
1080p/25	1080p/50

5. OSD show or hide setting

1) Select the items that need to be displayed on the OSD, check **Save the OSD setting parameters**, and click OSD settings



2) Hide all OSD: Select the options below shown, and click OSD settings, OSD hidden



Note: Each time power on the payload, check **Save the OSD setting parameters**, and click **OSD settings button**, you can only save the settings once. Clicking on the OSD settings again will not save one more time. To save new settings, you need to restart the payload.